



MICROFLASH 2Te

User Guide ■■■



microFlash 2te Printer: Top View	1
Using the Battery: General Guidelines	2
Charging the Battery	2
Determining Battery Condition	2
Installing Paper	3
Printing a Self-Test	4
Clearing Linerless Paper Jams	5
Removing a Paper Jam	5
Avoiding a Paper Jam	5
Cleaning Guidelines	7
Cleaning the Printhead	10
Configuring the Printer	12
Using Printer Data Cables	13
Using Bluetooth	14
Bluetooth Parameters	14
Using Buttons, LEDs, and Audio Indicators	15
Button Functions	15
LED Indicators	15
Audio Indicators	17
CardReader Audio Indicators	17
Using a CardReader	18
General Guidelines	18
Media Supplies	22

microFlash 2te Printer: Top View



NOTE: When the cable plug is inserted into the Power Port, the cable plug must lay horizontally to the bottom of the surface of the case.

Using the Battery: General Guidelines

If the printer has not been used for a long period of time, it may be necessary to recharge the battery. For more information, see *Charging the Battery on page 2*.

Charging the Battery

If the battery is low when the printer “wakes up,” the printer sounds three short beeps. Plug the AC Adapter into an appropriate power source and into the Power Port on the printer. The Charge LED will flash and progress from red (when the battery is very low in power) to orange, and then to a solid green when the battery is fully charged. A complete charge takes approximately 2.5 to 3.5 hours.

Note: To obtain full battery capacity, a new battery must cycle through two to three complete depletions and recharges.

Note: To restart a charge, unplug the power cord. Wait 30 seconds, then replug the power cord.

Determining Battery Condition

To determine the battery's condition, print a self-test. For more information, see *Printing a Self-Test on page 4*. The battery voltage varies between 5.8 and 8.0 volts.

Caution: There is a risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Caution: The operating temperature of this portable printer is 50° C. However, the operating temperature when used with Datamax-O'Neil power supply for charging the portable printer is limited to 40° C. Please charge the printer in a suitable location that meets this temperature requirement.

Caution: (For US/Canada) Please only use the Datamax-O'Neil part number 220240-100 power supply with this product.

Installing Paper

1. Insert a roll of paper with the end of the roll exiting from the bottom of the paper cavity (Figure 3).
2. Open the print head by raising the green, print head release lever until it stops (Figure 4).



Figure 3



Figure 4

3. Wake up the printer by briefly pressing the green, self-test button (Figure 5).

4. Feed the end of the paper under the roller. The paper automatically feeds under the roller and exits from the top of the print head. Verify the paper exits straight.




Figure 5

5. Lower the green, print head release lever (Figure 6).
6. Feed the paper through the printer's cover (Figure 7).



Figure 6



Figure 7

7. Close and latch the printer's cover.
8. Tear off any excess media.

Printing a Self-Test

1. After installing the paper, open the printer's cover.
2. Press and hold the green, self-test button for approximately five seconds until printing begins.
3. After printing begins, release the green, self-test button.

Clearing Linerless Paper Jams

Note: The following applies to printers that are designed for linerless paper.

A paper jam may occur if an Datamax-O'Neil printer with linerless paper installed is left in a cold environment without being used for an extended period of time (such as overnight).

Removing a Paper Jam

Note: Do not use a knife to fix the paper jam. This may cause damage to the printer roller underneath the paper.

1. Open the print head by raising the print head release lever until it is fully open. Do not stop at the partial open position.
2. Roll the media tightly onto the spool.



Figure 8

Avoiding a Paper Jam

There are two options to help avoid paper jams with linerless paper.

Remove the Linerless Paper from the Print Head

If the printer is going to be in a cold environment for a long period of time, remove the linerless paper from the print head. The paper can remain in the printer.



Figure 9

Advance the Paper

When the printer is turned on, hold the paper and then advance the paper. Verify the paper exits the print head straight.



Figure 10



Figure 11

Cleaning Guidelines

The following steps are intended to show how to clean MF2Te printers that use receipt media. These steps do not include cleaning media with adhesives.

The printer needs to be cleaned when any of the following conditions occur:

- Debris is on the printhead or after every ten (10) rolls of media are used (Figure 12).
- Dust and/or debris is found on the roller or print-head (Figures 12 and 13).
- The printout is light, faded, or characters are missing (Figures 14 and 15).

Note: Do not use a pen, screwdriver, or other sharp object when cleaning; it may cause damage to the printer that could void the warranty. Use only the Datamax-O'Neil Thermal Printer Cleaning Card (P/N 770015-001).



Figure 12 - dirty roller



Figure 13 - dirty roller

S	ABC Associates, Inc	S	ABC Associates, Inc		
O	123 Park Ave.	H	123 Park Ave		
L	Huntington, NY, 11743	I	Huntington, NY, 11743		
D		P			
T		T			
O		O			
ITEM NO.	DESCRIPTION	QUANTITY	UNIT PRICE	EXTENSION	
200060-A00	PENTIUM 4 1GHZ, 1GRAM	55	\$909.00	\$49,995.00	
280103-A00	PRINTER TONER (BLACK)	55	\$ 10.50	\$ 577.50	
280104-B00	PAPER COPY (BLACK) 3	55	\$ 0.00	\$ 0.00	
210050-B00	DATA CABLE - DB9F	2	\$ 35.00	\$ 70.00	
210050-B19	CABLE, PARALLEL	55	\$ 72.00	\$ 3,960.00	
490008-A01	AC POWER ADAPTER (110 V.)	55	\$ 24.00	\$ 1,320.00	
510002-A02	USB CABLE ADAPTER	54	\$ 12.00	\$ 648.00	
550028-A00	BATTERY, BACKUP DR 30AA	54	\$ 85.00	\$ 4,590.00	
740009-B00	PRINTER TONER (WHITE)	1,000	\$ 1.80	\$ 1,800.00	
110053-C00	PENTIUM LAPTOPBOOK	1	\$ 39.95	\$ 39.95	

Figure 14 - faded printout

T O QUANTITY	UNIT P
55	\$909.0
55	\$ 10.6
55	\$ 0.0
2	\$ 35.0
55	\$ 72.0
55	\$ 24.0
54	\$ 12.0
54	\$ 85.0
1,000	\$ 1.8
1	\$ 39.9
TOTAL ORDER VALU	

Figure 15 - faded printout

Cleaning the Printhead

1. Open the case.



Figure 16

2. Raise print head release lever.



Figure 17

3. Tear open the cleaning card's packaging.



Figure 18

4. If the printer is not awake, briefly press the red self-test button. The printer will automatically feed the cleaning card, the card will feed under the roller and then exit the top of the print head.



Figure 19

5. When the card is in the proper position, lower the printhead release lever. Next, press the red self-test button continuously to feed the cleaning card over the roller and through the printhead.



Figure 20

Keep the lid open to allow the printer to dry. After feeding the card through the printer once, remove and discard the cleaning card.

Configuring the Printer

The printer has many configurable settings. To configure or upgrade firmware, download the latest Windows configuration program at www.datamax-oneil.com.

Using Printer Data Cables

1. Select the appropriate cable for use with the host/device you are using.
2. Insert the plug into the printer data port (Figure 12).




Figure 21

3. Lead the cable through the notch on the outside of the printer cover.
4. With the cable exiting the front of the printer, close and latch the printer cover.

Note: When closing the printer, be cautious of the cable that is exiting to prevent pinching of the cable. Remove the cable when the printer is not in use.



Figure 22

Using Bluetooth

Note: The following information applies to printers with Bluetooth capabilities.

Radio printers are configured with default factory settings. To determine your printer's radio configuration, print a self-test. (For more information, see *Printing a Self-Test on page 4*.) If you have multiple printers, configure them specifically for use in your environment.

For proper system operation, set the following parameters on your printer and host computer:

Bluetooth Parameters

- Device Name
- Authentication
- Bondable
- Discoverable
- Connectable
- Encryption

For information on setting parameters, see *Configuring the Printer on page 12*. Contact your network administrator to verify the proper radio settings for your environment.

Using Buttons, LEDs, and Audio Indicators

Button Functions

Green Self-Test Button

Short press	If printer is asleep; printer wakes up. If printer is awake; paper feeds.
-------------	--

Long press (press and hold for five seconds)	Prints a self-test.
--	---------------------

Bluetooth Power Button

Short press	If printer is asleep and RF power is off; printer wakes up and RF power is turned on. If printer is asleep and RF power is on; printer wakes up and RF power is turned off. If printer is awake and RF power is off; RF power is turned on. If printer is awake and RF power is on; RF power is turned off.
-------------	--

LED Indicators

Bluetooth LED Indicators

LED	Description
Blue flash - fast	RF power is on and printer is awake.
Blue flash - slow	RF power is on and printer is asleep.
Off	RF power is off.

Charge LED Indicators

LED	State of Charge	Action
Flashing Orange Flashing Red	Charge in progress.	Wait for the charge LED to turn green.
Green	Charge complete.	None.
Red flash - slow	Battery is too cold.	Change environment.
Red flash - fast	High temperature.	Change environment.
Red to orange solid	Battery voltage is very low.	Wait for solid red. Restart charge.
Red to orange flash - fast	Battery voltage is too high.	Replace battery.
Orange flash - slow	Charge timeout.	Restart battery charge.
Orange flash - fast	Internal error.	Reset printer.

Power LED Indicators

LED	State of Charge	Action
Solid green	Printer is on.	None.
Black	Printer is off.	Printer needs to be turned on using the Green self-test button. Printer needs to be recharged.

Audio Indicators

Beep(s)	Description	Action
1	Printer wakes up.	None.
2	Out of paper.	Install paper.
3	Low battery.	Charge battery.
1 short	RF power is on (when blue, RF power button is pressed and power was turned off).	None.
2 short	RF power is off (when blue, RF power button is pressed and power was turned on).	None.
1 long	Boot code is starting or restarting (when downloading new firmware).	Redownload firmware.
8 short	CRC error in firmware.	Redownload firmware.

CardReader Audio Indicators

Beep(s)	Description	Action
1 long	Bad read.	Reswipe card.
2 short	Good read.	None.

Using a CardReader

Note: The following information applies to printers installed with the CardReader option.



Figure 23

General Guidelines

To use the CardReader, swipe a card with the stripe facing toward the printer, then slowly move the card left or right in the CardReader slot.

For information on CardReader LED indicators and audio indicators, see *Using Buttons, LEDs, and Audio Indicators* on page 15.

Agency Approvals

FCC Notice

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been verified to comply with the limits for a class B computing device, pursuant to FCC Rules. Operation with non-approved equipment is likely to result in interference to radio and TV reception.

The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter within 20 centimeters.

INDUSTRY CANADA STATEMENT

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Applicable Directive

- 89/336/EEC, 73/23/EEC

Applicable Standards

- EN55022 (1998)
- EN55024 (1998)
- EN60950 (1992)



Copyright

This manual and any examples contained herein are provided "as is" and are subject to change without notice. Datamax-O'Neil makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Datamax-O'Neil shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples herein. This guide is copyrighted. All rights are reserved. This guide may not, in whole or in part, be reproduced, translated, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photographic, or otherwise, without the prior written consent of Datamax-O'Neil.

Media Supplies

Datamax-O'Neil offers seven certified grades of paper for use in the printers. Our certified supplies are guaranteed compatible — this important qualification means that rigorous performance and image life testing have been performed. Quality supplies are key to obtaining optimal image quality and print performance. Quality supplies are also the key to extending the life of the printer. Datamax-O'Neil strongly recommends using Datamax-O'Neil Certified Supplies only.

For more information, contact Datamax-O'Neil at (949) 458-6400.

Maintenance Supplies

We recommend that you follow a regular maintenance schedule using our cleaning card (or cleaning kit when using linerless labels). Datamax-O'Neil cleaning cards are designed to effectively remove dirt and other contaminants from the thermal printhead, rollers, and paper path...resulting in a clean, crisp image output — every time. Our cleaning kits remove any adhesive residue (when using linerless labels) in addition to dirt and other contaminants.

For more information, contact Datamax-O'Neil at (949) 458-6400.

For more information

For information about using the printer, contact Datamax-O'Neil at (949) 458-0500, or visit www.datamax-oneil.com

