

# SG20T

Tethered Scanner



**User's Guide**

Intermec Technologies Corporation

Worldwide Headquarters

6001 36th Ave.W.

Everett, WA 98203

U.S.A.

[www.intermec.com](http://www.intermec.com)

The information contained herein is provided solely for the purpose of allowing customers to operate and service Intermec-manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec Technologies Corporation.

Information and specifications contained in this document are subject to change without prior notice and do not represent a commitment on the part of Intermec Technologies Corporation.

© 2011 by Intermec Technologies Corporation. All rights reserved.

The word Intermec, the Intermec logo, Norand, ArciTech, Beverage Routebook, CrossBar, dcBrowser, Duratherm, EasyADC, EasyCoder, EasySet, Fingerprint, i-gistics, INCA (under license), Intellitag, Intellitag Gen2, JANUS, LabelShop, MobileLAN, Picolink, Ready-to-Work, RoutePower, Sabre, ScanPlus, ShopScan, Smart Mobile Computing, SmartSystems, TE 2000, Trakker Antares, and Vista Powered are either trademarks or registered trademarks of Intermec Technologies Corporation.

There are U.S. and foreign patents as well as U.S. and foreign patents pending.





# Contents

Before You Begin.....	viii
Safety Information.....	viii
Global Services and Support.....	ix
Warranty Information.....	ix
Web Support.....	ix
Telephone Support.....	ix
Service Location Support.....	ix
Who Should Read This Manual.....	x
Related Documents.....	x
Patent Information.....	xi

## **1 Introducing the SG20T Tethered Scanner..... 1**

What is the SG20T Tethered Scanner.....	2
Supported Interfaces.....	3
Powering the SG20T.....	3
Connecting the Interface Cable.....	4
Removing the Interface Cable.....	5
Accessories.....	6
Required Accessories.....	6
Optional Accessories.....	6
Desktop / Wall Mount.....	7
Desktop Adjustable Stand.....	7

## **2 Scanning with the SG20T..... 9**

Understanding the Lights.....	10
Intermec Ready-to-Work Indicator.....	10
Status Light.....	11
Understanding the Beeps.....	12
Scanning Bar Codes.....	12
Hands-Free Scanning.....	15
Autostand Triggering Mode.....	15

<b>3</b>	<b>SG20T Interfaces</b> .....	17
	USB Interface .....	18
	Connecting a USB Cable .....	18
	Setting up the USB Interface .....	19
	International Keyboard .....	19
	USB Cable Mode .....	21
	RS-232 Interface .....	23
	Connecting an RS-232 Cable .....	23
	Setting up the RS-232 Interface .....	24
	Baud Rate .....	24
	Data Bits .....	25
	Parity .....	25
	Stop Bits .....	25
	Keyboard Wedge Y-Cable Interface .....	26
	Connecting a Keyboard Wedge Y-Cable .....	26
<b>4</b>	<b>Configuring the SG20T Scanner</b> .....	27
	Basic Setup with Configuration Bar Codes .....	28
	Resetting Your Scanner .....	28
	Configuring the Postamble .....	28
	Hands-Free Scanning .....	29
	Optimizing Decoding .....	29
	Damaged 1-Dimensional Bar Codes .....	29
	Configuring Predefined Imager Modes .....	30
	DPM Mode .....	31
	Configuring Your System with EasySet .....	31
	Online Setup with EasySet .....	31
	Offline Setup with EasySet .....	32
<b>5</b>	<b>Troubleshooting and Maintaining the SG20T</b> .....	33
	Troubleshooting the SG20T .....	34
	Calling Product Support .....	34
	Problems and Possible Solutions .....	35

Maintaining the SG20T ..... 37  
    Upgrading the SG20T ..... 37  
    Scanner Recovery ..... 42  
    Cleaning the SG20T ..... 43

**A Specifications and Reading Distances** ..... 45

    Specifications ..... 46

    Reading Distances ..... 48

        SG20T1D ..... 49

        SG20THP, SG20THC ..... 50

# Before You Begin

This section provides you with safety information, technical support information, and sources for additional product information.

## Safety Information

Your safety is extremely important. Read and follow all warnings and cautions in this document before handling and operating Intermec equipment. You can be seriously injured, and equipment and data can be damaged if you do not follow the safety warnings and cautions.

This section explains how to identify and understand warnings, cautions, and notes that are in this document.



**A warning alerts you of an operating procedure, practice, condition, or statement that must be strictly observed to avoid death or serious injury to the persons working on the equipment.**



**A caution alerts you to an operating procedure, practice, condition, or statement that must be strictly observed to prevent equipment damage or destruction, or corruption or loss of data.**



**Note:** Notes either provide extra information about a topic or contain special instructions for handling a particular condition or set of circumstances.



## **Global Services and Support**

### **Warranty Information**

To understand the warranty for your Intermec product, visit the Intermec web site at [www.intermec.com](http://www.intermec.com) and click **Support > Returns and Repairs > Warranty**.

Disclaimer of warranties: The sample code included in this document is presented for reference only. The code does not necessarily represent complete, tested programs. The code is provided “as is with all faults.” All warranties are expressly disclaimed, including the implied warranties of merchantability and fitness for a particular purpose.

### **Web Support**

Visit the Intermec web site at [www.intermec.com](http://www.intermec.com) to download our current manuals (in PDF). To order printed versions of the Intermec manuals, contact your local Intermec representative or distributor.

Visit the Intermec technical knowledge base (Knowledge Central) at [www.intermec.com](http://www.intermec.com) and click **Support > Knowledge Central** to review technical information or to request technical support for your Intermec product.

### **Telephone Support**

In the U.S.A. and Canada, call **1-800-755-5505**.

Outside the U.S.A. and Canada, contact your local Intermec representative. To search for your local representative, from the Intermec web site, click **About Us > Contact Us**.

### **Service Location Support**

For the most current listing of service locations, go to [www.intermec.com](http://www.intermec.com) and click **Support > Returns and Repairs > Repair Locations**.

For technical support in South Korea, use the after service locations listed below:

**Awoo Systems**

102-1304 SK Ventium

522 Dangjung-dong

Gunpo-si, Gyeonggi-do Korea, South 435-776

Contact: Mr. Sinbum Kang

Telephone: +82-31-436-1191

Email: [mjyun@awoo.co.kr](mailto:mjyun@awoo.co.kr)

**IN Information System PTD LTD**

6th Floor

Daegu Venture Center Bldg 95

Shinchun 3 Dong

Donggu, Daegu City, Korea

E-mail: [jmyou@idif.co.kr](mailto:jmyou@idif.co.kr) or [korlim@gw.idif.co.kr](mailto:korlim@gw.idif.co.kr)

## Who Should Read This Manual

This guide is for the person who is responsible for installing, configuring, and maintaining the SG20T.

This guide provides you with information about the features of the SG20T, and how to install, configure, operate, maintain, and troubleshoot it.

## Related Documents

The Intermec web site at [www.intermec.com](http://www.intermec.com) contains our documents (as PDF files) that you can download for free.

### To download documents

- 1 Visit the Intermec web site at [www.intermec.com](http://www.intermec.com).
- 2 Click the **Products** tab.
- 3 Using the **Products** menu, navigate to your product page. For example, to find the CN3 computer product page, click **Computers > Handheld Computers > CN3**.
- 4 Click the **Manuals** tab.

If your product does not have its own product page, click **Support > Manuals**. Use the **Product Category** field, the **Product Family** field, and the **Product** field to help you locate the documentation for your product.

## **Patent Information**

Product is covered by one or more of the following patents:

4,882,476; 4,894,523; 4,953,113; 4,970,379; 4,988,852; 5,019,699;  
5,021,642; 5,038,024; 5,081,343; 5,095,197; 5,144,119; 5,144,121;  
5,182,441; 5,187,355; 5,187,356; 5,216,233; 5,216,550; 5,218,191;  
5,233,172; 5,241,488; 5,243,602; 5,258,606; 5,288,985; 5,308,966;  
5,342,210; 5,359,185; 5,389,770; 5,397,885; 5,414,251; 5,416,463;  
5,442,167; 5,464,972; 5,468,947; 5,468,950; 5,477,044; 5,486,689;  
5,500,516; 5,502,297; 5,504,367; 5,514,858; 5,534,684; 5,536,924;  
5,539,191; 5,541,419; 5,548,108; 5,550,362; 5,550,364; 5,565,669;  
5,572,007; 5,576,529; 5,594,230; 5,598,007; 5,608,578; 5,616,909;  
5,619,027; 5,640,001; 5,659,431; 5,672,860; 5,684,290; 5,719,678;  
5,729,003; 5,742,041; 5,761,219; 5,764,798; 5,777,308; 5,777,309;  
5,777,310; 5,786,583; 5,798,509; 5,798,513; 5,804,805; 5,811,776;  
5,811,777; 5,818,027; 5,821,523; 5,834,749; 5,837,987; 5,841,121;  
5,842,070; 5,854,478; 5,862,267; 5,869,840; 5,873,070; 5,877,486;  
5,878,395; 5,886,338; 5,895,906; 5,902,987; 5,902,988; 5,912,452;  
5,923,022; 5,936,224; 5,949,056; 5,969,321; 5,969,326; 5,979,768;  
5,987,192; 5,992,750; 6,003,775; 6,012,640; 6,016,960; 6,018,597;  
6,024,289; 6,034,379; 6,036,093; 6,039,252; 6,064,763; 6,095,422;  
6,097,839; 6,102,289; 6,102,295; 6,119,941; 6,128,414; 6,138,915;  
6,149,061; 6,149,063; 6,152,370; 6,155,490; 6,158,661; 6,164,542;  
6,164,545; 6,173,893; 6,195,053; 6,234,393; 6,234,395; 6,249,008;  
6,328,214; 6,330,975; 6,345,765; 6,356,949; 6,367,699; 6,375,075;  
6,375,076; 6,435,411; 6,484,944; 6,641,046; 6,669,087; 6,681,994;  
6,688,523; 6,732,930; 6,879,428; 6,889,903; 6,974,085.

There may be other U.S. and foreign patents pending.

***Before You Begin***

# 1


## Introducing the SG20T Tethered Scanner

This chapter provides an overview of the SG20T Tethered Scanner. This chapter covers these topics:

- **What is the SG20T Tethered Scanner**
- **Supported Interfaces**
- **Powering the SG20T**
- **Connecting the Interface Cable**
- **Removing the Interface Cable**
- **Accessories**

# What is the SG20T Tethered Scanner


The SG20T Tethered Scanner is a general purpose handheld scanner. The SG20T is lightweight, ergonomically designed, and it interfaces easily with Intermec computers and other host computers.



## ***SG20T Tethered Scanner***

The SG20T is available in the following models:

- 1D linear imager—SG20T1D-xxx
- High performance 2D area imager—SG20THP-xxx
- Health Care 2D area imager—SG20THPHC-xxx



**SG20T Scan Engine Option:** The scan engine option of your SG20T can be found in the first part of the configuration number. In this illustration, the scan engine option is SG20T1D for 1D linear imager.

## Supported Interfaces

The SG20T supports the following interfaces:

- USB—keyboard HID, virtual COM, IBM Sure POS, and HID POS
- Standard RS-232
- Keyboard wedge/Y-Cable


## Powering the SG20T

The SG20T is powered through the accessory cable that connects it to the host computer. Depending on your connection, power for the SG20T comes from either the host computer or an external power supply connected to the interface cable.

## Connecting the Interface Cable

The cable you use depends on the interface and host device. However all cables are connected to the scanner in the same way.

To connect the cable, insert it and press firmly until inserted all the way.






## Removing the Interface Cable

To remove the cable follow these steps:

- 1 Insert a pin or straightened paper clip into the release hole.
- 2 Push on the pin or paper clip while pulling out the cable.



# Accessories

There are several different accessories available. Here you will find a list of required and optional accessories.

## Required Accessories

You will need one or more of the following cables for your SG20T.

### *SG20T Cable List*

Cable	Part Number
USB cable (6 feet straight)	CAB-SG20-USBxxx
Keyboard wedge cable (6 feet "Y" straight)	CAB-SG20-KBWxxx
RS232 Cable, DB9 (6 feet straight)	CAB-SG20-SERxxx
Universal Intermec power supply 5V	851-089-xxx



**Note:** A power cord is also needed to plug in the power supply. The power cord needed depends on your country and is sold separately.

## Optional Accessories


The following accessories are optional.

### *SG20T Optional Accessories*

Cable	Part Number
Desktop / Wall Mount	Holder-SG20-xx
Desktop Adjustable Stand	Stand-SG20-xx

## **Desktop / Wall Mount**

The desktop/wall mount holder can be used to store the SG20T when you are not using it. You can attach the holder with screws either to a desk or to a wall.



**SG20T Desktop / Wall Mount Holder: P/N Holder-SG20-xx**

## **Desktop Adjustable Stand**

The desktop adjustable stand can be used to adjust the scanning angle when using the SG20T as a hands-free scanner (must change the default trigger setting) or to store it when you are not using it.



**SG20T Desktop Adjustable Stand: P/N Stand-SG20-xx**



# 2

## Scanning with the SG20T

This chapter explains how to scan bar codes and includes the following sections:

- **Understanding the Lights**
- **Understanding the Beeps**
- **Scanning Bar Codes**

# Understanding the Lights

The SG20T uses the Intermec Ready-to-Work™ light and Status light to communicate information about your scanner.

## Intermec Ready-to-Work Indicator

The Intermec-Ready-to-Work indicator™ (blue LED) indicates that the scanner is ready to scan bar codes. This light stays on all the time when the scanner is ready to work however your scanner will also flash status information using green and red lights. See the Status Light information in the next section.

### ***Blue Intermec Ready-to-Work Indicator***

Light State	What it Means
Off	Scanner is not ready to scan bar codes.
On	The SG20T is ready to scan bar codes.




**Note:** By default the Intermec Ready-to-Work light is enabled however you can disable the light if desired. You can also change the color. See EasySet version 5. 6. 5. 1. for more information.

## Status Light

The status light on the SG20T flashes red or green depending on the status of the scanner.

### Default Status Light Description

Light State	What it Means
Series of green flashes (USB interface only)	<p>Power-up</p> <p>At power-up the status light flashes to indicate the activated USB interface:</p> <ul style="list-style-type: none"> <li>–1 flash = Keyboard HID</li> <li>–3 flashes = Virtual COM</li> <li>–5 flashes = HID POS</li> <li>–6 flashes = IBM POS Hand Held</li> <li>–7 flashes = IBM POS Table Top</li> </ul> <p>The status light only flashes at power up for a USB interface.</p> <p> <b>Note:</b> When changing from one USB interface to another the scanner restarts and will also flash the current USB interface.</p>
Green light on for 2 seconds	The scanner successfully decoded a bar code and sent the data to the host device.
Green light flashes 2 times	A configuration bar code was successfully read.
Red light on for 2 seconds	<p>Transmission error</p> <p>OR</p> <p>Configuration bar code was not accepted</p>

## Understanding the Beeps

The SG20T also beeps to give you audio feedback when performing some functions. For example, you hear a beep each time you scan a valid bar code.

### **Default SG20T Beep Descriptions**

Beep Sequence	What it Means
Two beeps	Power-up
Single beep	The scanner successfully scanned a bar code.
Two fast beeps	Configuration bar code successfully scanned
Six very fast beeps	Transmission error OR Configuration bar code was not accepted

## Scanning Bar Codes



**For the SG20THP and SG20THPHC do not look directly into the window area or at a reflection of the laser framing beam while scanning. Long-term exposure to the laser framing beam can damage your vision.**

The SG20T contains either a 1D linear imager (SG20T1D) or 2D area imager (SG20THP or SG20THC) to scan bar code data. The type of scan engine you are using and the type of bar code you are decoding determines the way you scan the bar code.

When you unpack the SG20T, these bar code symbologies are enabled:

- Code 39
- Code 128 / GS1-128
- EAN/UPC
- PDF417 (SG20THP and SG20THPHC only)
- DataMatrix (SG20THP and SG20THPHC only)



If you are using bar code labels that are encoded in a different symbology, you need to enable the symbology on your SG20T. Use EasySet version 5.6.5.1 or later to enable and disable symbologies for your scanner.

**To scan a bar code label with a 1D linear imager**

- 1** Point the SG20T at the bar code label and hold the SG20T at a slight angle 15 to 25 cm (6 to 10 in) from the label.
- 2** Pull the trigger, and direct the red beam so that it falls across all bars in the bar code label.

Use this test bar code:

Code 39 Test Bar Code




\*123456\*

**Tip:** Depending on your screen resolution, you can scan bar codes displayed on your computer screen.

By default, when the SG20T successfully reads a bar code label, the SG20T beeps one time, the status light briefly turns green, and the scanner beam turns off.


- 3** Release the trigger.



**Scanning Bar Codes:** The aiming and scanner beams that you see depend on which SG20T model you are using.

**To scan omni-directionally with the 2D high performance area imager**

- 1 Point the scanner window at the bar code label and hold the SG20T steady a few inches from the label.
- 2 Pull the trigger and use the laser framing to position the imager over the bar code or area to capture.



**SG20THP Laser Framing**



When bar code labels are printed close to each other, try to frame only the bar code you want to read, to avoid reading the wrong bar code.

By default, when the SG20T successfully reads a bar code label, the SG20T beeps one time, the status light briefly turns green, and the scanner lighting turns off.

- 3 Release the trigger.

## **Hands-Free Scanning**

The SG20T is a handheld scanner however you can scan items without having to hold your scanner in your hand. To do hands-free scanning, you will need to change the triggering mode to Autostand. To activate, see **“Hands-Free Scanning” on page 29**.

### **Autostand Triggering Mode**

Autostand mode is different depending on the scanner model. This section explains the difference between:

- Autostand for SG20THP/SG20THPHC and
- Autostand for SG20T1D

#### **Autostand For SG20THP or SG20THPHC**

Autostand is a mix of Level and Presentation triggering modes. When in Level mode you simply pull the trigger to scan a bar code (hand held scanning). After a period of inactivity the scanner switches to Presentation mode (configurable timeout). In this mode the scanner turns on automatically when it detects movement in front of the scanner window. This allows you to use your scanner for hands-free scanning. To return to Level mode pull the trigger.

#### **Autostand For SG20T1D**

When using the 1D model Autostand is a mix of Level and Flashing triggering modes. When in Level mode you simply pull the trigger to scan a bar code (handheld scanning). After a period of inactivity the scanner switches to Flashing mode (configurable timeout). When the scanner is flashing you can present a bar code in front of the scanner window and it will be scanned. To return to Level mode pull the trigger.



# 3

## SG20T Interfaces

This chapter explains the different interfaces available with the SG20T:

- **USB Interface**
- **RS-232 Interface**
- **Keyboard Wedge Y-Cable Interface**



# USB Interface

The SG20T can be connected to a USB host using one of the USB cables. The SG20T is USB 2.0 and operates at full speed. Power is provided either by the host or by the external power supply connected to the USB cable. See the **“Accessories” on page 6** for a list of part numbers for the different cables.

## Connecting a USB Cable

### To connect with a USB cable

- 1 Connect the USB cable to your SG20T and to the host.



- 2 Connect the power supply to the cable and an AC power outlet if you are using the externally powered USB cable.

- 3 If your host device is off, turn it on. The scanner beeps twice and the green LED flashes to indicate the USB interface (see **“Status Light” on page 11**).



**Note:** If you are using a non-powered USB cable, you may get a message that the host does not provide enough power. For example when you connect the USB cable to a keyboard hub or if there are other USB devices connected. In this case use a different hub or disconnect other USB devices. Otherwise use a powered USB cable.

- 4 If necessary, use the configuration bar codes in the next section to configure your SG20T for an International keyboard. The default keyboard is North America.

## Setting up the USB Interface

This section provides configuration bar codes for a basic USB interface setup. All bar codes marked with (\*) indicate the default value. For more configuration options see **Chapter 4, “Configuring the SG20T Scanner” on page 27**.

### International Keyboard

By default the SG20T uses a North American keyboard layout. Use these configuration bar codes to select the keyboard for your country. Additional keyboards are available in EasySet (see **“Configuring Your System with EasySet” on page 31**).

North American Windows (\*)



French Windows



French Canadian Windows 95/98



French Canadian Windows XP/2000



German Windows



Spanish Windows



Italian Windows



Swedish Windows



UK English Windows



Japanese Windows



Brazilian Portuguese Windows



Czech Republic Windows



Slovakian Windows





Hungarian 101-Key



### USB Cable Mode

By default the USB cable mode is set to keyboard HID. However you can also set up your scanner to use the following USB cable modes:

- HID POS
- IBM POS Hand Held
- IBM POS Table Top
- Virtual COM

USB Keyboard HID (\*)



HID POS



IBM POS Hand Held



IBM POS Table Top



USB Virtual COM



**Note:** When scanning a USB Cable Mode configuration bar code, the scanner beeps twice then restarts. When it restarts it will beep twice and flash a series of green flashes to indicate the USB cable mode (see **“Status Light” on page 11**).

### **USB Virtual COM Driver**

For a first time setup when using the virtual COM USB cable mode you will need to download and install the driver. You can download the driver from Knowledge Central on the Intermec web site.

#### **To download the USB virtual COM driver:**

- 1** Go to <http://intermec.custhelp.com>.
- 2** In the search box type “SG20T USB driver” and click **Search**.
- 3** Download the driver and instructions.
- 4** Follow the installation procedure provided in Knowledge Central.

After you have installed the driver and set your scanner to USB Virtual COM mode, open the Intermec Virtual Com Port (for example using EasySet or any hyper terminal) before scanning bar codes.


# RS-232 Interface

The SG20T can be connected to a host using one of the RS-232 cables. Power is provided by the external power supply connected to the RS-232 cable. See the “**Required Accessories**” on page 6 for a list of part numbers for the different cables.

## Connecting an RS-232 Cable

### To connect with an RS-232 cable

- 1 Turn off your host device.
- 2 Connect the RS-232 cable to your SG20T and the host.



- 3 Connect the power supply to the cable and an AC power outlet.
- 4 Turn on the host device. The scanner beeps twice.
- 5 If necessary, use the configuration bar codes in the next section to configure your SG20T serial parameters to match the PC.

The default serial parameters for the SG20T are:

Serial Parameter	Default Setting
Baud rate	57600
Data bits	8
Parity	None
Stop bits	1

## Setting up the RS-232 Interface

This section provides configuration bar codes for a basic setup. All bar codes marked with (\*) indicate the default value. For more configuration options see [Chapter 4, "Configuring the SG20T Scanner" on page 27](#).

### Baud Rate

38400



115200



230400



57600 (\*)



128000



256000



460800



**Data Bits**

7



8 (\*)



**Parity**

None (\*)



Even



Odd



**Stop Bits**

1 (\*)



2




# Keyboard Wedge Y-Cable Interface

The SG20T can be connected to a host using a keyboard wedge Y-cable. Power is provided either by the host or by the external power supply connected to the cable. See the **“Required Accessories”** on [page 6](#) for a list of part numbers for the different cables

## Connecting a Keyboard Wedge Y-Cable

### To connect with a keyboard wedge Y-cable

- 1 Turn off your host device.
- 2 Connect the Y-cable to your SG20T.



- 3 Connect one end of the Y-cable to your host device and the other end to a PS2 keyboard. If your host device does not provide enough power, connect the power supply to the Y-cable and an AC power outlet.
- 4 Turn on your host device. The scanner beeps twice.
- 5 If necessary, configure your SG20T for an International keyboard (see **“International Keyboard”** on [page 19](#)). The default keyboard is North America.

# 4

## Configuring the SG20T Scanner

This chapter provides some basic configuration bar codes and information on how to configure the SG20T using the EasySet configuration application. This chapter includes:

- **Basic Setup with Configuration Bar Codes**
- **Hands-Free Scanning**
- **Optimizing Decoding**
- **Configuring Your System with EasySet**

## Basic Setup with Configuration Bar Codes

This chapter provides you with configuration bar codes for a basic setup. For more configuration options, use EasySet (see [“Configuring Your System with EasySet” on page 31](#)).

### Resetting Your Scanner

To reset your scanner, read the reset factory defaults configuration bar code.

Reset factory defaults



### Configuring the Postamble

The default postamble is <CR> <LF>. For certain applications or when using USB Keyboard HID you may need to change this setting. Use the following configuration bar codes to change the default postamble in your scanner.

Carriage Return + Line Feed (\*)



None



Carriage Return



Enter





## Hands-Free Scanning

For hands-free scanning as explained in “[Hands-Free Scanning](#)” on [page 15](#) activate Autostand triggering mode by scanning this configuration bar code:

Autostand Triggering Mode



## Optimizing Decoding

Use the following barcodes to optimize your scanner reading performance.



**Note:** These configuration bar codes are only for the SG20THP and SG20THPHC models.

## Damaged 1-Dimensional Bar Codes

If you are reading 1D bar codes that are damaged or badly printed, enable this setting to enhance the ability to read these types of bar codes.

Damaged 1D Codes - Enable



Damaged 1D Codes - Disable (\*)



## Configuring Predefined Imager Modes

When using a 2D model (SG20THP or SG20THC), you can optimize the reading performance of the scanner by adjusting certain parameters. Since there are many parameters that can be adjusted, we recommend using the pre-defined imager settings to quickly set up your imager for optimized reading. The pre-defined imager settings take in to account the type of bar code, environment and reading surface.

There are 4 pre-defined imager settings:

- 1-Dimensional bar codes only
- Standard 1-dimensional and 2-dimensional bar codes
- 1-Dimensional and 2-dimensional bar codes in a bright environment
- 1-Dimensional and 2-dimensional bar codes with reflective surface (shiny labels)

Select the pre-defined imager setting that best suits your needs:

1D bar codes only



Standard 1D and 2D bar codes (\*)



Standard 1D and 2D bar codes, bright environment



Standard 1D and 2D bar codes, reflective surface



## DPM Mode

Direct Product Marking (DPM) is when the bar code is marked directly on the product. Enabling DPM Mode when scanning DPM bar codes optimizes reading this type of code.

DPM mode - Enable



DPM mode - Disable (\*)



**Note:** DPM mode is not required to be able to read DPM bar codes but may be necessary when scanning hard to read DPM bar codes.

## Configuring Your System with EasySet

EasySet is an Intermec configuration application that provides you with two ways to configure your scanner.

- Online setup—send configuration commands from EasySet directly to the product.
- Offline setup—send configuration commands to a bar code setup sheet, print the setup sheet and use a connected scanner to scan the bar codes.

EasySet is available on the Intermec web site at [www.intermec.com/EasySet](http://www.intermec.com/EasySet). Simply download and install.

### Online Setup with EasySet

Online setup with EasySet is only available if you are using an RS-232 cable or a USB cable.

#### To configure your scanner online by sending commands from EasySet

- 1 Connect the scanner to a host PC using an RS-232 or USB cable and set connection parameters if necessary.

- 2 Start EasySet. The first time you start EasySet, the Select product dialog box appears.  
If the Select product dialog box does not appear, choose **Product > Select** or click on the product icon in the upper left corner.
- 3 Select your product (SG20T).
- 4 Select **Communication > Select Communication Interface**. The **Device Selection** dialog box appears.
- 5 Select the communication interface that you are using for your system and click **OK**.
- 6 EasySet connects to your scanner and retrieves the current configuration. These configurations are indicated with a blue check mark or blue text. Open the folders to find the configuration commands needed. Double click each command to send it to the scanner.



**Note:** The scanner does not beep when you send configuration commands online from EasySet.

## Offline Setup with EasySet

### To configure your scanner offline by scanning bar codes

- 1 Start EasySet. The first time you start EasySet, the Select product dialog box appears.  
If the Select product dialog box does not appear, choose **Product > Select** or click on the product icon in the upper left corner.
- 2 Select your product.
- 3 Open the folders to find the configuration commands needed. Double-click each command to send each command to the setup sheet.
- 4 Click on the print icon to print out the setup sheet and scan the commands.

# 5

## Troubleshooting and Maintaining the SG20T

Use this chapter to solve problems you may have while using the SG20T. This chapter contains these topics:

- **Troubleshooting the SG20T**
- **Maintaining the SG20T**

# Troubleshooting the SG20T

If you have problems using the SG20T, use this chapter to find a possible solution.

## Calling Product Support

To talk to an Intermec Product Support representative:

- In the U.S.A. and Canada, call **1-800-755-5505**
- Outside the U.S.A. and Canada, contact your local Intermec representative. For help, go to [www.intermec.com](http://www.intermec.com) > **About Us** > **Contact Us**.

Before you call Intermec Product Support, make sure you have the following information:

- SG20T firmware version
- SG20T decode version

There are two methods to get the firmware and decode version:

- by opening a data collection application and reading the Get firmware version and Get decode version bar codes - recommended when using a USB Keyboard HID or keyboard wedge interface, or
- by opening EasySet and retrieving the scanner current configuration - recommended when using an RS-232 or USB Virtual Com interface (but also possible with a USB Keyboard HID interface).

### To get the firmware version and decode version by reading bar codes

- 1 Run an application that can accept bar code information from the SG20T (for example, Microsoft® Notepad).
- 2 Scan one of these bar codes:

Get firmware version



Get decode version



### To get the firmware version and decode version in EasySet

- 1 Follow the procedure for an online setup with EasySet (see [“Online Setup with EasySet” on page 31](#)).
- 2 When the scanner is connected to EasySet, open the Configuration modes and utilities folder in EasySet. The default firmware and decodes versions appear in blue next to the Get firmware version and Get decode version entries.


## Problems and Possible Solutions

Use this section to find possible solutions to problems you may have.

### *Problems and Possible Solutions*

Problem	Possible Solution
You pull the trigger, but nothing happens.	The SG20T receives power from either a host or an external power supply through an accessory cable. Make sure: <ul style="list-style-type: none"><li>• You are using the appropriate cable. For more information, see <a href="#">“Required Accessories” on page 6</a>.</li><li>• The cable is connected to the appropriate port on the host computer.</li><li>• The universal power supply (if necessary) is properly plugged in.</li></ul>

**Problems and Possible Solutions (continued)**

Problem	Possible Solution
<p>You pull the trigger, the red scanning beam turns on, but you cannot successfully scan a bar code.</p>	<p>Try these possible solutions:</p> <ul style="list-style-type: none"> <li>• Make sure that the SG20T is configured for the symbology you are scanning.</li> <li>• Make sure that the SG20T is at the appropriate scanning distance from the bar code. Move the SG20T closer and farther away to find the appropriate distance.</li> <li>• Make sure that the SG20T is configured for the type (1D, 2D) of bar code you are scanning.</li> <li>• Make sure the bar code you are trying to scan is not poorly printed or too small. Scan a known good bar code to make sure that the SG20T is working properly.</li> </ul> <p>For more information, see <b>“Scanning Bar Codes” on page 12.</b></p>
<p>You scan a bar code and the status light turns on, but the SG20T does not beep.</p>	<p>The beep duration, volume, frequency, and number may be configured so that the SG20T does not beep.</p>
<p>You scan a configuration bar code and the SG20T beeps six very fast beeps.</p>	<p>The SG20T does not recognize or support the configuration bar code you scanned.</p>
<p>You scan a bar code, the SG20T beeps once, and the status light blinks green once, but the data is not transmitted to the host computer.</p>	<p>Try these possible solutions:</p> <ul style="list-style-type: none"> <li>• Make sure that your data collection application is set up to receive data from the SG20T.</li> <li>• If you are using an RS-232 cable, make sure that the serial parameters on the SG20T match the serial parameters of the host computer. The default serial parameters for the SG20T are: 57600 baud, 8 data bits, no parity, and 1 stop bit.</li> </ul>
<p>You cannot scan the Firmware upgrade bar code on your computer screen.</p>	<p>Print out this bar code and scan it:</p> <p><b>Firmware upgrade</b></p> 



# Maintaining the SG20T

To keep your SG20T in good working order, you may need to upgrade the SG20T firmware and clean the scanner window.

## Upgrading the SG20T

You may need to upgrade the SG20T firmware if there is an update that incorporates changes to a feature or adds functionality to the scanner. When you upgrade your scanner the current settings are erased and replaced with the default settings. The process of upgrading the SG20T takes about 10 minutes to complete.

To upgrade the SG20T you need:

- An RS-232 or USB cable. For more information on cables, see **“Required Accessories” on page 6**.
- Minimum PC operating system requirements are Microsoft® Windows® XP with SP2 or Microsoft Windows 2000 with SP4 or higher versions.
- EasySet version 5.6.5.1 (see **“Configuring Your System with EasySet” on page 31**) or later.
- The firmware update file (.bin).



**Note:** Before you start the upgrade process, make sure that you are not using the selected COM port for any other application or you receive an error and cannot use the COM port.

### To upgrade the SG20T firmware

- 1 Download the latest SG20T firmware update package from the Intermec web site at [www.intermec.com](http://www.intermec.com).
  - a Go to **Support > Downloads**.
  - b From the **Product Category** drop-down list, choose **Bar Code Scanners**.
  - c From the **Product Family** drop-down list, choose **Tethered**.
  - d From the **Product** drop-down list, choose **SG20T Hand Held Scanner** and click **Submit**.


- e** Click the link to download the firmware upgrade package and save firmware upgrade file (.bin) to your PC.
- 2** Connect your SG20T to a host PC with the appropriate cable.




**Note:** If using a USB cable, you must use the USB Virtual Com USB cable mode.

- 3** Start EasySet version 5.6.5.1 or later.
- 4** From the **Tools** menu, select **Upgrade product firmware** to start WinFlash.
- 5** If WinFlash is not already installed you will be asked to install it. Click **Yes** and follow the installation instructions. After installing Winflash, start WinFlash from the **Tools** menu, select **Upgrade product firmware**.

**6** Select the cable and click **Next**.



- 7 Use **Browse** to browse to the location of the firmware upgrade file (.bin), select the file, and click **Open**. Click **Next**.




- 8 For USB cables only, scan the **Firmware upgrade** bar code that appears on the screen. The scanner disconnects and reconnects (can take up to 4 or 5 seconds). Click **OK**. For other cables, go directly to the next step.



**Note:** If your scanner cannot scan the bar code on your computer screen see **“Problems and Possible Solutions” on page 35** to find the firmware upgrade bar code. Print the page out and scan the bar code.

- 9 Select the Com port and parameters (if necessary) and deselect the **Display help** check box. Click **Next**.




- 10 Click **Start download**.

For RS-232 cables only, scan the **Firmware upgrade** bar code that appears on the screen and click **OK**.



**Note:** If your scanner cannot scan the bar code on your computer screen see **“Problems and Possible Solutions” on page 35** to find the firmware upgrade bar code. Print the page out and scan the bar code.



When the firmware download is complete, the “Operation successful” message appears.

- 11 Click **Finish**. You have successfully upgraded your scanner firmware.



**Note:** If the firmware download is not successful, you must restart the firmware download procedure.

## Scanner Recovery

If something happens to your scanner and it does not turn on despite using the correct cables and power supply, the only way to recover the scanner is to reinstall the firmware. This is only possible with a download cable. Please contact your Intermec representative.

## **Cleaning the SG20T**

Clean the scanner window as often as needed for the environment in which you are using the SG20T. To clean the scanner window, you can use soapy water, a solution of ammonia and water, or isopropyl alcohol.



**Caution**

**Opening the SG20T voids the warranty and may cause damage to the internal components.**

### **To clean the scanner window**

- 1** Dip a clean towel or rag in soapy water, ammonia and water solution, or isopropyl alcohol and wring out the excess. Wipe the scanner window. Do not allow any abrasive material to touch the window.
- 2** Wipe dry with a lint-free cloth.





# A

## Specifications and Reading Distances

This appendix contains the technical specifications and reading distances for each scanner model.

# Specifications

Use this section to find technical information about the SG20T

Physical Dimensions	
Length	20 cm (7.9 in)
Height	6.5 cm (2.6 in)
Width	6.1 cm (2.4 in)
Weight	125 g (4.4 oz)

Electrical Specifications	
Electrical rating	≡ 5V, 1.7 A

Typical Power Consumption—Continuous Scanning (5V power supply, ambient lighting, continuous scanning)	
SG20T1D	RS-232 = 120 mA
	USB = 120 mA
	Keyboard wedge = 120 mA
SG20THP, SG20THC	RS-232 = 300 mA
	USB = 320 mA
	Keyboard wedge = 330 mA

Typical Power Consumption (5V power supply, ambient lighting, idle after turning on, not scanning)	
SG20T1D	RS-232 = 60 mA
	USB = 70 mA
	Keyboard wedge = 120 mA
SG20THP, SG20THC	RS-232 = 50 mA
	USB = 70 mA
	Keyboard wedge = 50 mA

**Interfaces**

RS-232, USB, Keyboard Wedge

**Temperature and Environmental Specifications**

Operating temperature	0°C to 50°C (32°F to 122°F)
Storage temperature	-20°C to 60°C (-4°F to 140°F)
Relative humidity	5 to 95% non-condensing
Shock	30 G, 11 ms half-sine, 3 directions
Vibrations	8G, from 10Hz to 500Hz, 2hr/axis, 3 axes
Environmental rating	IP30
Ambient light	0 to 100 000 lux
Artificial light	25 000 lux

**Scanning Performance**

SG20T1D	Scan angle: 38° Minimum X dimension: 6 mils (0.15 mm)
SG20THP, SG20THC	Scan angles: 34.4° horizontal, 22.2° vertical Framing angles: 30° horizontal, 20° vertical Min. X dimension 1D: 4 mils (0.1 mm) Min. X dimension 2D: 6.6 mils (0.17 mm)

**Bar Code Symbolologies for 2D Models (SG20THP, SG20THC)**

Australian Post	Infomail
Aztec	Intelligent mail
BPO	Interleaved 2 of 5
Canada Post	Japan Post
Codabar	Matrix 2 of 5
Codablock A	Maxicode

## Appendix A – Specifications and Reading Distances

### Bar Code Symbologies for 2D Models (SG20THP, SG20THC) (continued)

Codablock F	Micro PDF417
Code 11	MSI
Code 39	Multicode
Code 93/93i	PDF417
Code 128 / GS1-128	Planet
DataMatrix	Plessey
Dutch Post	Postnet
EAN/UPC	QR Code
GS1 Composite	Standard 2 of 5
GS1 DataBar Expanded	Sweden Post
GS1 DataBar Limited	Telepen
GS1 DataBar Omni-Directional	TLC 39
GS1 DataBar Stacked	


### Bar Code Symbologies for 1D Model (SG20T1D)

Codabar	GS1 DataBar Limited
Code 11	GS1 DataBar Omni-Directional
Code 39	Interleaved 2 of 5
Code 93/93i	Matrix 2 of 5
Code 128 / GS1-128	MSI
EAN/UPC	Plessey
GS1 Composite (linear only)	Standard 2 of 5
GS1 DataBar Expanded	Telepen

## Reading Distances


The reading distances for each scanner are typical distances measured from the front end of the scanner bezel in an office environment (200 lux).

# SG20T1D



Symbology	Density	Minimum Distance	Maximum Distance
Code 39	0.15 mm (6 mils)	6 cm (2.36 in)	13 cm (5.12 in)
	0.25 mm (10 mils)	3 cm (1.18 in)	21 cm (8.26 in)
	0.5 mm (20 mils)	3 cm (1.18 in)	32 cm (12.6 in)
	1 mm (40 mils)	8 cm (3.15 in)	50 cm (19.68 in)
EAN/UPC	0.33 mm (13 mils)	3 cm (1.18 in)	26 cm (10.24 in)

# SG20THP, SG20THC



Symbology	Density	Minimum Distance	Maximum Distance
Code 39	0.125 mm (5 mils)	4 cm (1.57 in)	12.5 cm (4.92 in)
	0.5 mm (20 mils)	5 cm (1.97 in)	46 cm (18.11 in)
	1 mm (40 mils)	12 cm (4.72 in)	70 cm (27.56 in)
EAN/UPC	0.33 mm (13 mils)	4 cm (1.57 in)	30 cm (11.8 in)
PDF417	0.25 mm (10 mils)	3 cm (1.18 in)	25 cm (9.84 in)
	0.38 (15 mils)	3 cm (1.18 in)	35 cm (13.78 in)
DataMatrix	.025 mm (10 mils)	3 cm (1.18 in)	19 cm (7.48 in)





Worldwide Headquarters  
6001 36th Avenue West  
Everett, Washington 98203  
U.S.A.

tel 425.348.2600

fax 425.355.9551

[www.intermec.com](http://www.intermec.com)

© 2011 Intermec Technologies  
Corporation. All rights reserved.

## SG20T Tethered Scanner User's Guide



P/N DOC-SG20T-UG01